




<u>Enclosure no 3</u> Lublin, 02.10.2023

Maintenance instructions - PRIME ALUMINUM SYSTEM aluminum fences

Maintenance of an aluminium fence is relatively simple and can significantly extend its life and aesthetics. Following the recommendations below is the basis for warranty recognition. Here are the steps you should take to keep your aluminium fence in the best possible condition:

- 1. Regular cleaning regularly clean the aluminum fence from dust, dirt and sediment, using a soft cloth or sponge moistened with water and a mild detergent. Gently wash the fence surface and then rinse with clean water. Avoid cleaning products containing chemical solvents or irritating substances that may damage the aluminum or paint coating. Do not wash the fence with a steam jet or pressure washer. Do not use abrasive cleaners or clean the surface by rubbing. For best results, it is recommended to clean on a cloudy or rainy day.
- **2.** Lubricate the gate drive components (if present) according to the drive manufacturer's recommendations. This will prevent corrosion and ensure smooth operation.
- **3. Inspection for loose or damaged components** regularly check the fence for loose screws, locks or other components that may pose a hazard during use. Please remember that adjusting and leveling your gate is a normal maintenance and care activity that is the responsibility of the fence owner.
- **4. Weather protection** try to protect your fence from extreme weather conditions such as sunstroke, rain, snow and frost. This will help to preserve its aesthetics and durability for longer. Avoid using gates and wickets on very windy days as this risks failure.











5. Tidy up around the fence - make sure there are no leaves, branches or other items that may damage or contaminate the fence around the fence.

Remember that effective maintenance of an aluminum fence depends on regular activities and immediate response to any damage. With these steps, you will be able to enjoy a beautiful and functional fence for many years.

The maintenance instructions are an integral part of the General Warranty Conditions available on the website https://tabal.pl/alufence/

